

marantz^e

Integrated Amplifier HD-AMP1

Quick Start Guide

Start Here
Commencez ici
Iniciar aquí

Before you begin

What's In The Box











HD-AMP1

Power cord

Remote and batteries

Product manual on CD-ROM

USB cable

Required For Setup





Speakers

Speaker cable

Optional





PC or MAC

iPod/iPhone and USB cable

- For more information, visit www.marantz.com
- Refer to the enclosed CD-ROM manual or Online Manual for other functions information and operation procedure details.


manuals.marantz.com/HDAMP1/NA/EN/





Français

1. Connection



2 Connect the power cord from the HD-AMP1 to a power outlet

3 Insert the batteries into the remote

2. Installing the Windows driver software

NOTE: Mac users will use the built-in driver software. No installation is required.

- Download the dedicated driver from the "Download" section of the HD-AMP1 page of the Marantz website (http://www.marantz. com/pages/home.aspx) onto your PC.
- 2 Unzip the downloaded file, and double-click the exe file

- 3 Install the driver.
- Select the language to use for the installation.
- 2 Click "OK".



- 3 The wizard menu is displayed. Follow the instructions on the screen.
- 4 When the wizard is completed, click "Yes".




Basic trouble shooting

- The driver software cannot be installed correctly if your PC is connected to the unit by a USB cable.
- If the unit and your computer are connected by a USB cable and the computer is switched on before installation, disconnect the USB and restart the computer.
- Please see the FAQ at www.marantz.com if you experience any issues getting audio to play from your computer through the HD-AMP1. You may also want to check the support pages for your audio player application.

3. Enjoying your music!

Enjoying music from your PC or Mac

1 Connect the HD-AMP1 to your PC or Mac using the included USB cable.



2 Power on.



3 Press the "USB-DAC" button on the remote.



4 On your PC or Mac, select the HD-AMP1 as the current output device.


System Requirements

- Windows 7 or 8/8.1
- Mac OS X 10.9 or 10.10

Windows OS


- 1 Click the "Start" button and click "Control Panel" on the PC.
 - The control panel setting list is displayed.
- 2 Click the "Sound" icon.
 - The sound menu window is displayed.

- Make sure under "Playback" tab the "HD-AMP1" is set as "Default Device" indicated by the checkmark.
 - When there is a checkmark for a different device, click
 "HD-AMP1" and "Set Default".
- Select "HD-AMP1" and click "Properties".
 - The Digital Audio Interface Properties window is displayed.



5 Click the "Advanced" tab.


- 6 Select the sampling rate and bit rate to be applied to the D/A converter.
 - It is recommended that "24 bit, 192000 Hz (Studio Quality)" or "32 bit, 192000 Hz (Studio Quality)" is selected.
- Click "Apply".
- 8 Click "Test".
 - Check that audio is heard from the speakers connected to the HD-AMP1.



- 1 From the Finder, select the Utilities menu item from the Go menu.
 - The utility list is displayed.
- 2 Double-click "Audio MIDI Setup".
 - The "Audio Devices" window is displayed.
- 3 Check that "Use this device for sound output" is checked in "HD-AMP1".
 - If a different device is checked, select and "Secondary click" on "HD-AMP1", and then select "Use this device for sound output".



- 4 Select the "HD-AMP1" format.
 - It is normally recommended to set the format to "384000.0 Hz" and "2ch-32 bit Interger".



5 Click "Quit Audio MIDI Setup".

- Use your favorite music applications on your PC/Mac to play audio through the HD-AMP1.
 - For high resolution audio playback you will need to obtain an advanced audio player software such as JRiver Media Center or Audirvana.




The sampling frequency of the music file is displayed.

Note

 Additional settings to output audio to the HD-AMP1 may have to be selected in your advanced audio player application.
 Please refer to the user's manual for your application.

Enjoying music from your iOS device


1 Connect your iOS device to the USB port on the front of the HD-AMP1 using the cable that came with your iOS device.



2 Press the iPod/USB button on the remote.




3 Use your favorite music applications on your iOS device to play audio through the HD-AMP1.



Enjoying music from your USB storage devices


1 Connect your USB storage device to the USB port on the front of the HD-AMP1.



2 Press the iPod/USB button on the remote.



3 After the contents of your device are loaded, use the remote to select something to play.



www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz[®] is a registered trademark.